

Bath Bombs

Ingredients

4oz baking soda

2oz corn starch

2oz citric acid

2oz Epsom salts

1-1 ½ tsp water

1 tsp essential oil

1 ¼ tsp teaspoon olive oil

1-2 drops food coloring

Directions

1. In a bowl combine the dry ingredients and whisk to remove any clumps.
2. Stir together the wet ingredients in another bowl.
3. Slowly pour the liquid mixture in with the dry mixture, stirring as you go. If you see the mixture fizz or foam, you may be adding the liquid too quickly.
4. Once all the wet ingredients are combined with the dry, take a small amount in your hand and squeeze it together. If it's still too powdery just add a tiny bit more water and mix until it does hold together.
5. Then fill each half of the mold with the mixture until it's just overflowing a little. Press together, then gently remove one side of the mold. Place the bath bomb on a tray and allow to dry out for 10-12 minutes before removing the other side. Once you are ready to remove the other side, gently invert the bath bomb so the uncovered side is facing down, then gently remove the other half of the mold from the top.
6. Once they are completely out of the mold, allow them to dry out for 8 hours or overnight. Once very dry, you can wrap them in plastic wrap and store in a dry place.